26/03/2021

**Validated** 

## Resp.:

**GPR CALIB** 



Tools / Components

Item to Install / Uninstall


Tool






Operation 1 : Install the GPR300

| Basic operations                  | Security | Self-Controle  | Instruction                        | Gestual |
|-----------------------------------|----------|--|------------------------------------|---------|
| 1- Load the product on the bench  |          |  | Poka-Yoke                          |         |
| 2- Connect the product            |          |  |                                    | 0       |
| 3- Unlock the cart                |          |  | Unlock the latch Push the cart     |         |
| 4- Insert the pole                |          |  | Put the locating bolt horizontally |         |
| 5- Lock                           |          |  | 1/4 turn                           |         |
| 6- Place the product in the coil  |          | Until the gray mark is correctly positioned          | Push with the pole                 |         |
| 7- Check that the cart is blocked |          | Move the pole back and forward until the cart locks. |                                    | 0       |





Operation 2: Uninstall the GPR300

| Basic operations              | Security | Self-Controle | Instruction             | Gestual |
|-------------------------------|----------|---------------|-------------------------|---------|
| 1- Insert the pole            |          |               | Put the locating bolt   |         |
|                               |          |               | horizontally            |         |
|                               |          |               | Insert in the fastening |         |
|                               |          |               | system                  |         |
|                               |          |               | Lock the pole: 1/4 turn |         |
| 2- Unlock the cart            |          |               | Press the pedal         |         |
|                               |          |               | The cart unlocks.       |         |
| 3- Take out the cart          |          |               | Pull with the pole      |         |
| 4- Completely remove the cart |          |               | Until the latch is      |         |
|                               |          |               | locked                  |         |
| 5- Take off the pole          |          |               | Unlock the pole         |         |
| 6- Unplug the connector       |          |               |                         | 0       |
| 7- Store the connector        |          |               |                         | 0       |
| 8- Remove the GPR300          |          |               |                         | 0       |



